



From Nomorobo's Help Desk

Go to nomorobo.zendesk.com, then click on "Nomorobo Setup" and then "AT&T U-verse"


1. Login to [myAT&T](#).
2. Hover over **Home Phone** at the top of the page, and then select [Manage Features](#).




3. From the **Feature Controls** section, select **Locate Me**.
4. Select the **On** radio button.



5. Enter the toll-free Nomorobo Number shown in your control panel. Click Add.



6. Click **Save**.



7. After you've completed those steps, go back to your Nomorobo dashboard and click the **"Next"** button. Then click **"I'm ready. Call Me Now."**

OR

Go to **"Your Phones"** and click **"Test"** next to your number.

You will immediately receive a call letting you know if everything is setup correctly. Please pick up the phone after the third ring.

8. Your number will now be listed as **"Protected"**.